

# AC ELECTRICAL

12V BATTERY CHARGER	110 VOLT AC	230V AFT CABIN	230V CAPTAINS	230V FLOODS AFT	230V FOCISLE	230V GALLEY	230V MAIN CABIN	24V BATTERY CHARGER	380 VOLT AC	110 V AC SOCKETS
110 V AC SOCKETS	AIRCON FWD/GUEST	AC CHANGEOVER SWITCH	AC MONITORING	AFT SOCKETS	AIR COMPRESSOR	AC AMPS	AC/DC CONVERTER	AC VOLTS	AIR CONDITIONING	AIR CON 1
AIR CON 2	AIR CON AFT	AIR CON CHILLER 1	AIR CON CHILLER 2	AIR CON CREW AREA	AIR CON FWD	AIR CON GALLEY	AIR CON PORT	AIR CON PUMP 1	AIR CON PUMP 2	AIR CON SALOON
AIR CON STBD	AIR HANDLER 1	AIR HANDLER 2	AIR HANDLER 3	AC OUTLETS	BLACK WATER PUMP	BALLAST PUMP	BREAD MAKER	BATTERY CHARGER	BATTERY CHARGER 1	BATTERY CHARGER 2
BATTERY CHARGER 3	BATTERY CHARGER 4	BATTERY CHARGER 12V	BATTERY CHARGER 24V	BOILER	CREW SOCKETS	CHARGER 1	CHARGER	COMPUTER	COOKER	COOKER CERAMIC
COOKER HOOD	DVD PLAYER	DISHWASHER	DIVE COMPRESSOR	DRYER	ENGINE ROOM SOCKETS	ENGINE ROOM FAN	EXTERNAL OUTLETS	EARTH LEAKAGE BREAKER	FRESH WATER PUMP	FIRE PUMP
FWD SOCKETS	FOSCLE SOCKETS	FANS	FREEZER	FREQUENCY	FWD TV	GUEST CABIN SOCKETS	GENSET MONITORING	GREY WATER PUMP	GENERATOR	GENERATOR
GENERATOR 1	GENERATOR 2	GENERATOR PREHEAT	GENERATOR START	GENERATOR STOP	GALLEY SOCKETS	HI FI	HOB	INVERTER	INVERTER 1	INVERTER 2
INVERTER 3	INVERTER 4	INVERTER 5	INVERTER 3 PHASE	INVERTER 110 V	INPUT TO COMBI	INTERIOR SOCKETS	ICEMAKER 1	ICEMAKER 2	JAQUZEE	LOAD GROUP 1
LOAD GROUP 2	LOAD GROUP 3	LOAD GROUP 4	LOAD SENSOR	MASTERSWITCH	MICROWAVE OVEN	MACERATOR	MAIN BREAKER	MINI DISC PLAYER	MASTER CABIN SOCKETS	NIGHT GENERATOR
NORMAL POLARITY	OUTLET AC 1	OUTLET AC 2	OUTLET AC 3	OUTLET AC 4	OVEN	ON - OFF	OUTLET AC 1	OUTLETS AC 220 VOLT	PORT GENERATOR	PORT SOCKETS
PLASMA SCREEN	PARALLEL	REVERSE POLARITY	RCD	RCD SHORE	RCD GENERATOR	RCD HIGH POWER	RCD INVERTER GROUP	SHORE	SHORE	SHORE
SHORE	SHORE 1	SHORE 2	SHORE SUPPLY AMPS	SHORE SUPPLY VOLTS	SHORE MONITORING	STBD GENERATOR	STBD SOCKETS	SALOON SOCKETS	TRASH COMPACTOR	VOLTS AC